## Thinking of you Electrolux



#### Connection kit


### This connection kit is designed for use on the following top mount, bottom mount and single door refrigerators and freezers whose total body height is 1720 mm.

The model numbers and overall dimensions of individual products are:

model	description	max door height (H)	cabinet height (H1)	total height (H2)	door width (W)	cabinet width (W1)	total depth (D)	cabinet depth (D1)	depth door open (D2)
ETM5207SA-R	520 It Top Mount, RH Door	1720	1702	1720	800	790	735	612	1450
ETM5207SA-L	520 It Top Mount, LH Door	1720	1702	1720	800	790	735	612	1450
ETM4407SA-R	440 It Top Mount, RH Door	1720	1702	1720	700	690	735	612	1350
ETM4407SA-L	440 It Top Mount, LH Door	1720	1702	1720	700	690	735	612	1350
EBM5107SA-R	510 It Bottom Mount, RH Door	1720	1702	1720	800	790	735	612	1450
EBM5107SA-L	510 It Bottom Mount, LH Door	1720	1702	1720	800	790	735	612	1450
EBM4307SA-R	430 It Bottom Mount, RH Door	1720	1702	1720	700	690	735	612	1350
EBM4307SA-L	430 It Bottom Mount, LH Door	1720	1702	1720	700	690	735	612	1350
ERM3707SA-R	370lt Single Door Refrigerator, RH	1720	1702	1720	605	595	672	550	1193
EFM3007SA-L	300lt Single Door Freezer, LH	1720	1702	1720	605	595	673	550	1193


All measurements are in millimetres


#### Single cabinet dimensions




#### Joined dimensions

Note: It is possible to join together cabinets of different depth. In such a case one cabinet will be 62 mm shorter at the back.







#### Joined cabinet dimensions:

individual ca (W		cabinet height	max door height	joined cabinet width	joined door width	max total depth	max cabinet depth
model 1	model 2	(H1)	(H)	(Wa)	(Wb)	(D)	(D1)
790	790	1702	1720	1600	1612	735	612
790	690	1702	1720	1500	1512	735	612
790	595	1702	1720	1405	1417	735	612
690	690	1702	1720	1400	1412	735	612
690	595	1702	1720	1305	1317	735	612
595	595	1702	1720	1210	1222	673	550

All measurements are in millimetres

#### Before you begin

- Thoroughly inspect cabinets for any signs of damage before commencing installation.
- If any damage is identified please contact Electrolux Service.
- Check refrigerator recess dimensions and ensure that they provide at least the minimum clearance at the back, side and top as recommended on page 2.
- The floor where the refrigerator is to be placed must be level otherwise you will not be able to install your refrigerator properly.
- Ensure that the floor and surrounding cupboards are adequately protected from damage during unpacking and throughout the installation process.
- Ensure that two adequate and accessible power points are installed inside the refrigerator recess before installing and connecting your appliances. These power points should also be readily accessible after fridge installation is completed.
- Do not use extension leads or power board or double adapter under any circumstances as it may lead to electric shock and / or fire. Seek assistance of a licensed electrician if required.
- Unpack the connection kit and check for completeness by referring to the "Connection kit package content" section.

#### Note:


Due to size and weight of the cabinets as well as complexity of the task ensure that installation is attempted with at least two able-bodied persons. You are strongly urged to consider hiring Electrolux Service to do the installation.

#### Connection kit package contents

	description	qty
	Lower front bracket assembly	1
	Top bracket	1
	Top bracket screw	6
e e e	Rear clamp	1
	Centre cover assembly	1
	Centre cover top screw	2
	Disposable protective foam	2
	Protective cardboard – provisional top bracket assembly	1
	Rear adjustable roller	4
	Tape	1


#### Installation procedure

 Tape disposable protective foam to the door and rear edge of the cabinet on one of the products before commencing any work and attempting to bring the cabinets closer together. Foam should be applied to the front and rear edge of the cabinet.




Secure protective foam to the side of the cabinet using tape supplied in the connection kit. Foam should be secured on the handle side of the cabinet.

 Your appliance is delivered with three hole plugs filling the screw holes for the top bracket. Those holes are located on the top of the cabinet, opposite from the door hinge. Carefully remove hole plugs using a small screwdriver or a knife. Care must be taken to avoid damage to the refrigerator/freezer when removing the plugs.



Carefully remove hole plugs from holes to allow fitment of the top bracket.


3. Provisionally join the two cabinets at the top with the top bracket and screws, placing the protective cardboard between the bracket and cabinets. This will provide adequate protection of the cabinets against scratching while they are only temporarily joined at the top and manipulated for installation purposes.




4. Provisionally join the two cabinets together at the back, near the compressor, using the rear clamp. Loosen the fasteners connecting the compressor mounting plate to the cabinet and engage rear clamp, leave the fasteners partially loose at this stage.



Do not remove compressor mounting fasteners as this may cause the appliance to loose stability.



Leave the compressor mounting plate fastener partially loose after engaging the rear bracket. This hole on the rear bracket is used only when two cabinets of different depths (D1) are being joined together (i.e. 690 + 595 model or 790 + 595 model).



Two cabinets of different depths joined at the back with rear clamp. Notice that compressor mounting plate fasteners are in different location on the rear clamp.


5. Join the two cabinets at the front lower end using the bottom bracket. To enable this, have an assistant tilt the two provisionally joined cabinets approximately 30 degrees. Before performing any work underneath the cabinets ensure that assistant has full grip of the cabinets and that you can clearly and concisely communicate with your assistant.

Ensure that you use timber, foam or similar items to support and secure the tilted cabinets. Care must be taken to avoid damage of cabinets, compressor, copper tubing and floor. Use masonite or similar to protect the floor from scratching before the cabinets are tilted.




#### tips and information

Ensure enough distance away from island benches when performing this action



Tilt the cabinet back by no more then 30 degrees. This will enable adequate access to the front feet in order to install lower bracket. Ensure that assistant has firm grip of the cabinets before continuing. Use chocks or other means of firmly supporting the cabinets before attempting further installation work. The cabinets can be best tilted by having assistant pull and support the appliances from the back.

6. With the cabinet tilted back loosen the two large adjusting roller nuts to allow for assembly of the bottom bracket. Secure the bottom bracket with the large adjusting nuts, ensure that both rollers are adjusted to approximately the same height to facilitate easier cabinet leveling at a later stage.



7. With the two cabinets provisionally connected level both units using adjustable rollers as per recommendations in your owner's manual. Gently push the assembly back into the wall cavity and check for alignment and level. If necessary, pull the cabinets out again and adjust, repeat the procedure until satisfied with level and alignment.




#### tips and information

If the cabinets still are not level after adjusting front rollers, follow the steps below to fit and adjust rear adjustable rollers. This must be done before securing the two cabinets together.


#### Notes:

- This is a two man operation and should be done before the two cabinets are connected with the connection kit.
- Rear adjustable rollers are required on cabinets and can be installed on 430L, 440L, 510L and 520L cabinets only.
- Tilt the cabinet forward by approximately 30° ensuring stability in tilted position.
- Insert the rear adjustable rollers into the existing slots in the base plate at the rear of the refrigerator. Push them until they click into position.
- Remove the auxiliary drain pan and discard before installing the rear adjustable rollers.

Note: Auxiliary drain pan is present on 500L models only




- Lower both cabinets gently ensuring the appliance rests on both rear adjustable rollers.
- Wind the rear adjustable rollers up or down along with the front adjustable rollers to raise or lower the cabinet and match the height with respect to the adjacent cabinet.
- 8. When satisfied with levelling and alignment fully secure rear clamp, remove the top bracket and protective cardboard and the front disposable protective foam, insert the center cover by engaging it into the tensioner on the bottom bracket. Gently push the centre cover between the two cabinets, place the top bracket back on top of the two cabinets and ensure that it is fully engaged with the centre cover. Fully secure the top bracket with six fasteners.



Engage the center cover piece into the tensioner of the bottom bracket. To facilitate this loosen the tensioner if required.


# Fasten clamp

Adjust tension on centre cover for flush mounting with cabinets.



Tension on the center cover can be adjusted with the screw on the bottom bracket

10. Secure the centre cover piece to the top bracket with the single, self tapping fastener.




- 11. Push the appliances back into the wall cavity, ensure adequate clearance is maintained to the back and on each side of the cabinets (see page 2).
- 12. Wind the stability foot on both cabinets down until they just touch the hard floor surface.

#### Adjusting door alignment

To complete installation of your joined appliances it may be necessary to slightly adjust door alignment on the individual appliance. This process is illustrated in the following section


1. With the door open remove the hinge cover by simultaneously pulling the cover away and up from the hinge. This action will release the clip that is retaining the cover to the hinge.



Small plastic clip is located here. With the door open pull the cover outward while simultaneously pulling up in order to release the hinge cover.

Slightly loosen the three screws retaining the hinge to the cabinet. This will allow for slight movement of the cabinet door.

Have the assistant hold the door in desired position and fully secure top hinge fasteners, inspect the alignment and if satisfied clip the hinge cover back onto the top hinge.



Loosening the top hinge fasteners will allow the top hinge to be slightly rotated thus adjusting the gap between doors.



Hinge screw torque must be between 5-10nm to ensure doors are held securely.



Print code: ELINEREFCK Issue date: Dec 06